



GETTING TO KNOW

SUPER CRUISE



chevrolet.com

Review this Quick Reference Guide for an overview of the Super Cruise™ driver assistance feature. More information can be found in your Owner's Manual and at my.chevrolet.com. For easy reference, keep this guide with your Owner's Manual in your glove box.

Questions? Contact a Chevrolet Customer Assistance Advisor at 1-800-222-1020.

Certain restrictions, precautions, and safety procedures apply to your vehicle.
Please read your Owner's Manual for complete instructions.



SUPER CRUISE OVERVIEW



While using the Super Cruise™ driver assistance feature, always pay attention while driving and do not use a handheld device. Visit chevrolet.com/supercruise for compatible highways and more information. Operation requires an active and eligible Connected Services plan, active Wi-Fi hotspot, working electrical system, cell reception, and GPS signal.

SUPER CRUISE OPERATION

Super Cruise is a hands-free driver assistance feature for use on compatible highways. The system steers the vehicle to maintain lane position, under certain conditions, while also monitoring your attention to the road. Working with the Adaptive Cruise Control system, it reduces the need for you to frequently steer, brake, or accelerate under available operating conditions.

When Super Cruise is engaged, the vehicle's real-time cameras, sensors, and GPS, used in conjunction with the precision LiDAR map data, keep the vehicle centered in its lane and traveling along the lane path while the driver's hands are removed from the steering wheel.

Always pay attention while driving and do not use a handheld device, even while using the Super Cruise driver assistance feature. Visit chevrolet.com/supercruise for compatible highways and more information.

HOW SUPER CRUISE WORKS

The Super Cruise driver assistance feature is available only on compatible highways that are separated from opposing traffic. The GPS uses real-time corrections and map data to determine the vehicle's location while the Lane Sensing Camera detects the marked lanes on the highway to help the vehicle steer and maintain lane position.

The system works with Adaptive Cruise Control, which detects vehicles traveling in the same direction in your path and accelerates or brakes the vehicle to maintain a driver-selected following distance gap from a vehicle detected ahead, even in stop-and-go traffic conditions.

When engaged, Super Cruise provides feedback on system status while tracking driver head position and eye gaze. An escalating series of prompts lets you know whether the Driver Attention Camera senses that you need to pay more attention to the road ahead. The alerts will prompt you to pay close attention to the road and to steer manually when needed.

The steering wheel light bar intuitively provides a status of system operation, including when the system is steering and when you need to manually steer the vehicle. You can override Super Cruise at any time by steering, braking or accelerating.

In situations in which the driver doesn't respond to the series of Super Cruise alerts, the vehicle will come to a controlled stop in its lane and an OnStar advisor will be connected to the vehicle to provide support. Super Cruise will be disabled until the next ignition cycle.

See Driving and Operating in your Owner's Manual.

SUPER CRUISE OPERATION

It's extremely important that you pay attention to the operation of the vehicle, even while using Super Cruise. Always be prepared to take over operation of the vehicle at all times.

Super Cruise:

- Does not prevent crashes or warn of possible crashes.
- Does not steer to avoid stopped or slow-moving vehicles, cross-traffic, construction barriers or cones, motorcycles, children, pedestrians, animals, or other objects on the road.
- Does not steer in response to vehicles or objects next to your vehicle, including vehicles attempting to enter your lane.
- Does not respond to traffic lights, stop signs, or other traffic-control devices.
- Does not respond to crossing or oncoming traffic.
- Does not make turns.
- Does not steer to merge onto or to exit highways.
- Does not steer to avoid or steer through construction zones.
- Does not function on surface streets or in city driving conditions.

See Driving and Operating in your Owner's Manual.

ENGAGING SUPER CRUISE

SUPER CRUISE AVAILABILITY




Super Cruise is available to be used only when:

- Adaptive Cruise Control is On.
- The vehicle is on a compatible highway, which generally only allows high-speed traffic and is separated from opposing traffic.
- Camera or radar sensors are not obstructed or damaged.
- Lane markings are clearly visible. Do not use Super Cruise in poor weather conditions or when visibility is limited.
- Driver attention is detected.
- Teen Driver is not active.

Super Cruise should not be used in complex or uncertain driving conditions, including: in construction zones; when approaching an intersection controlled with a traffic light, stop sign or other traffic-control device; on winding or hilly roads; in tunnels; or in heavy traffic. Always make sure traffic conditions are safe before using Super Cruise.


See Driving and Operating in your Owner's Manual.



ENGAGING SUPER CRUISE

1. To use the Super Cruise driver assistance feature, Adaptive Cruise Control must be On.
2. Press the  **Adaptive Cruise Control** button (A) on the steering wheel to turn on the system. The  symbol (C) will illuminate in white on the instrument cluster. If the system is already set, the  will be green with a speed shown.

Note: Press and hold the  **Cancel** button to switch from regular Cruise Control to Adaptive Cruise Control.

3. When Super Cruise detects you are on a compatible highway and paying sufficient attention, and all other driving conditions are met (lane markings visible, GPS available, no system faults, etc.), the Super Cruise symbol (D) will illuminate in white on the instrument cluster.

4. When it is safe to do so, press the  Super Cruise button (B) on the steering wheel to engage Super Cruise. The symbol (E) and steering wheel light bar illuminate in green when Super Cruise is steering the vehicle.

If Super Cruise is engaged and the  symbol and steering wheel light bar illuminate in blue, the driver is still in control of steering and Super Cruise is not steering the vehicle. Position the vehicle in the center of the lane until the  symbol and light bar turn green.

5. Once Super Cruise controls the steering, traffic and other conditions and laws permit, and it is safe to do so, your hands can be taken off the steering wheel. The vehicle can be steered manually at any time.

When Super Cruise is engaged, the Forward Collision System will be set to the Alert and Brake setting.

If an Adaptive Cruise Control speed was not previously set, the current speed will be the cruise set speed used by Super Cruise.

- ▶ To disengage Super Cruise, press the  **Super Cruise** button again, press the brake pedal or pull the Regen-on-Demand paddle.



See *Driving and Operating* in your Owner's Manual.

STEERING WHEEL LIGHT BAR INDICATORS

When the Super Cruise driver assistance feature is not engaged, the light bar is not visible on the steering wheel and the Super Cruise symbol on the instrument cluster is illuminated in white or is not illuminated. You must steer the vehicle.

When Super Cruise is engaged, the steering wheel light bar and Super Cruise symbol indicate system status.

Solid Green Bar and Solid Green Symbol

Super Cruise is active and steering the vehicle. This is the only time you may remove your hands from the steering wheel.

Flashing Green Bar and Solid Green Symbol

Super Cruise is active, but the system detects that you need to pay more attention to the road.



Pulsing Blue Bar and Solid Blue Symbol

Super Cruise is active, but the system detects that you are manually steering. To return to Super Cruise steering, position the vehicle in the center of the lane and hold the steering wheel steady until the green indicators appear.



Flashing Red Bar, Solid Red Symbol, and Beeps Sound

You need to take steering control immediately. The system cannot operate properly under current conditions. The vehicle will begin to coast until you take steering control. Super Cruise must be re-engaged to use the system again.

Flashing Red Bar, Solid Red Symbol, Beeps Sound, and Voice Prompt

You need to take steering control immediately. A voice prompt will tell you to take over steering control. If you do not take steering control, the vehicle will steer and brake gradually to a stop. Super Cruise will not be available until the next ignition cycle.



ATTENTION ALERTS

DRIVER ATTENTION CAMERA

When the Super Cruise driver assistance feature is engaged, the Driver Attention Camera, located on top of the steering column, determines whether the driver's attention is on the road ahead. It works with infrared lights to track head position and eye gaze to determine where you are looking.

Note: The Driver Attention Camera does not record or share photos, audio, or video.

1ST ALERT

If the system detects that you may not be paying sufficient attention to the road ahead, the steering wheel light bar flashes green to prompt you to return your attention to the road.

The light bar will stop flashing when the system detects your attention to the road has resumed.

The Driver Attention Camera needs to see the driver's entire face clearly. If the steering wheel light bar flashes green while you are paying sufficient attention, your face may be obstructed. It may be necessary to adjust the angle of the steering wheel and your seating position.



2ND ALERT

If the steering wheel light bar flashes green for too long and the system detects continued inattentiveness to the road ahead, the steering wheel light bar flashes red and beeps sound to notify you to look at the road and steer the vehicle manually.

The vehicle will not accelerate while the light bar is flashing red.

The steering wheel light bar will also flash red when:

- Adaptive Cruise Control is canceled.
- The vehicle is on a tight curve or speed is too fast.
- Lane markings are poor or visibility is limited.
- The compatible highway ends.
- The vehicle is approaching an intersection controlled by a traffic light, stop sign, or other traffic-control device.
- There is a system fault.


3RD ALERT




If the steering wheel light bar flashes red for too long, a voice prompt will be heard. You should take over steering immediately; otherwise, the vehicle will slow in your lane of travel and eventually brake to a stop. Super Cruise and Adaptive Cruise Control will disengage.

In the event of an unresponsive driver, the vehicle will come to a controlled stop in its lane, activate the hazard lights, and contact OnStar Emergency Services.

See Driving and Operating in your Owner's Manual.

MESSAGING

The Super Cruise driver assistance feature may not be available or may disengage when active based on several operating conditions. Use the  **Super Cruise** button on the steering wheel to view instrument cluster messages about system operation.

- ▶ If the  Super Cruise symbol does not appear, press the  **Super Cruise** button to display a message about why the system is unavailable.
- ▶ Immediately after Super Cruise disengagement, press the  **Super Cruise** button (within 10 seconds) to display a message with the reason for disengagement.

Refer to your Owner's Manual for summaries of all messages.



See Driving and Operating in your Owner's Manual.

CHANGING LANES

The vehicle can be steered manually at any time when the Super Cruise driver assistance feature is engaged.



1. Verify the next lane is clear and conditions are safe to make a lane change. Always check the mirrors and use the turn signals.
2. Move the steering wheel manually. The steering wheel light bar pulses blue.
3. Steer the vehicle into the desired lane.
4. To allow Super Cruise to resume steering, center the vehicle in the lane until the light bar turns green.



See Driving and Operating in your Owner's Manual.

DRIVER ASSISTANCE INFORMATION

Driver Assistance information for Adaptive Cruise Control and Following Distance, and Lane Keep Assist, if enabled, can be viewed on the instrument cluster.

1. Press the  button on the steering wheel to display the Driver Information Center menus.
2. Use the thumbwheel on the steering wheel to scroll to the Info menu (A). Press the  thumbwheel.
3. Use the thumbwheel to display the Driver Assistance page.



See Instruments and Controls in your Owner's Manual.

CONNECTED SERVICES

REQUIRED CONNECTED SERVICES PLAN

Super Cruise functionality is enabled by a data connection for real-time, precise positioning and periodic Super Cruise map updates. In order to operate Super Cruise, an active and eligible Connected Services plan that includes OnStar Emergency Services is required.


To learn more about Connected Services, press the blue OnStar button, visit onstar.com, or call 1-888-466-7827.



See OnStar and Connected Services in your Owner's Manual.

MAP DATABASE

Find a Super Cruise™ road near you.



The Super Cruise driver assistance feature uses a LiDAR-scanned map database, which restricts system use to compatible highways.

Visit chevrolet.com/supercruise to view compatible highways near you.

MAP UPDATES

Super Cruise map updates and GPS enhancement data are automatically downloaded to the vehicle. Super Cruise will be disabled if updates do not occur and the map reaches 7 months old. Disabling the vehicle's Wi-Fi or Location Services in the Settings menu on the infotainment screen will disable automatic map updates.

In addition to the automatic updates, your Bolt EUV Authorized Chevrolet dealer can upload the latest Super Cruise map to the vehicle.

See Driving and Operating in your Owner's Manual.

DATA DOWNLOAD

Map database updates and GPS enhancement data are downloaded to the vehicle using the vehicle's 4G LTE Wi-Fi Hotspot. If a mobile device with its own Wi-Fi Hotspot uses the same name and password as the vehicle, the vehicle may connect to the mobile device to download the data.

To prevent downloading using a mobile device data plan, use a different name and password for the vehicle's Wi-Fi Hotspot and the mobile device, or disable the Wi-Fi Hotspot of the mobile device when inside the vehicle.

- ▶ To change the Wi-Fi Hotspot name and password, select the Wi-Fi Hotspot icon or go to Settings > System > Wi-Fi Hotspot.

See Infotainment System in your Owner's Manual.

USING SUPER CRUISE RESPONSIBLY

Super Cruise is a driver assistance feature. Your complete attention is always required while driving because unexpected steering or braking may occur if the system does not correctly detect lanes, vehicles or traffic situations ahead, or if situations occur that the system cannot detect, including cross-traffic. Do not use a handheld device while driving, even with Super Cruise engaged.

The system is designed to maintain the current lane. You need to take control to steer around a traffic situation or object, merge into traffic, exit the highway, make a turn, or stop for crossing traffic or a traffic light, stop sign or other traffic-control device. Super Cruise does not steer to avoid construction zones.

The system does not detect whether you are drowsy or focused on safe driving. Always be ready to take action and take over steering or apply the brakes.

Some state and local laws may not permit hands-free driving. In these locations, use Super Cruise by lightly holding the steering wheel at all times. Always know the rules in your area.

Super Cruise is available on additional roads, including areas of divided highways that have limited crossings. Under certain conditions, such as when approaching an intersection, Super Cruise uses the high-precision map to hand control of the vehicle back to you. It is important that you stay engaged and vigilant at all times while driving.

See Driving and Operating in your Owner's Manual.

SYSTEM CARE

The Super Cruise driver assistance feature operates using the front and rear radars, front camera, and Surround Vision cameras. Keep the surfaces of these systems clean for proper Super Cruise operation.

Clean the lens cover of the Driver Attention Camera on the steering column with a soft cloth sprayed with glass cleaner as needed.

Any required service on the Super Cruise system is recommended to be performed by a Bolt EUV Authorized Chevrolet dealer.

See Vehicle Care in your Owner's Manual.

MYCHEVROLET MOBILE APP

Download the myChevrolet Mobile App* today. Within the app, you can set up charge notifications, customize charge settings, and view mileage range, battery status, and state of charge. The app's Energy Assist features help with planning road trips, finding charging stations with real-time availability, and initiating a charge session at participating stations. When your phone is connected to your vehicle, the app will monitor energy usage during your trip. Model Year 2022 Bolt EUV owners receive up to 10 years of EV Access features to stay connected to their vehicle while on the go.

**Available on select Apple and Android devices. Service availability, features and functionality vary by vehicle, device and the plan you are enrolled in. Terms apply. Device data connection required. Visit onstar.com for details and limitations. Energy Assist does not provide turn-by-turn navigation. For details on Energy Assist, visit chevrolet.com.*

ROADSIDE ASSISTANCE

1-888-811-1926

TTY Users: 1-888-889-2438

As the owner of a new Chevrolet, you are automatically enrolled in the Chevrolet Roadside Assistance program for 5 years/60,000 miles, whichever occurs first, at no expense to you. The Chevrolet Roadside Assistance toll-free number is staffed by a team of trained advisors who are available 24 hours a day, 365 days a year to contact a service provider for light services (jump starts, flat tire and lock-outs) or make arrangements to tow your vehicle to the nearest Bolt EUV Authorized Chevrolet dealer.

ONSTAR ROADSIDE ASSISTANCE

If you have a current OnStar Safety & Security plan, push the blue **OnStar** button or red **Emergency** button to get the help you need. An OnStar advisor will use GPS technology to pinpoint your vehicle location and contact the nearest service provider.

To learn more about OnStar services, press the blue **OnStar** button, visit onstar.com, call 1-888-4-ONSTAR (1-888-466-7827), or refer to your Owner's Manual.

CHEVROLET OWNER CENTER

Get to know your vehicle inside and out with the Chevrolet Owner Center. Check out personalized information, including an online Owner's Manual and helpful how-to videos, track your service history and warranty status, manage your OnStar and Connected Services vehicle plans, review your current Vehicle Diagnostics report (active service account required) and more. Create an account today at my.chevrolet.com.

We recommend always using ACDelco or GM Genuine Parts.

Certain restrictions, precautions and safety procedures apply to your vehicle. Please read your Owner's Manual for complete instructions. All information contained in this guide is based on the latest information available at the time of printing and is subject to change without notice. Copyright 2021 General Motors. All rights reserved.



85152488