

CONGRATULATIONS ON YOUR CHEVROLET. PROTECT IT FOR THE ROAD AHEAD.

There's nothing like that new car feeling. And to help preserve its appearance and performance, we created the **Chevrolet Protection Plan**. It provides extended protection on top of the manufacturer's limited warranty — helping you avoid the high costs of repairs down the road. **It's the only Protection Plan backed by Chevrolet.**



- Lease-friendly, long-term and low-mileage plan options available
- Choose your deductible
- Platinum mechanical repair coverage including parts and labor for up to 8 years or 150,000 miles, whichever comes first²
- Rental car coverage reimburses you up to \$40 per day (max. 10 days³)
- 24-hour Roadside Assistance, up to \$100 per occurrence
- Trip interruption reimbursement up to \$200 a day (max. 5 days) if you break down 100 miles or more from home⁵



Pick the plan that best suits your needs — and your budget.

	Powertrain	Silver	2 Platinum
	Basic coverage	A more advanced coverage option	The most comprehensive coverage option
Engine	•	•	•
Transmission	•	•	•
Drive Axle(s)	•	•	•
Hybrid Electric	•	•	•
Front Suspension		•	•
Rear Suspension		•	•
Climate Control		•	•
Electrical		•	•
Steering		•	•
Brakes		•	•
Audio/High Tech			•
Navigation			•



Protection

1The Chevrolet Protection Plan is optional and is not insurance. All transactions related to the Chevrolet Protection Plan are governed solely by the provisions of the Chevrolet Protection Plan Vehicle Service Contract ("Agreement"). This document provides general information only. Refer to the Agreement for full terms, conditions, and coverage details, including limitations and exclusions. Coverage may vary by state. Not all vehicle models may be eligible for coverage. Please see your dealer for more information, including limitations and exclusions. The Obligor of the Chevrolet Protection Plan is GM Protections, LLC, 801 Cherry Street, Suite 3500 Fort Worth, TX 76102, 1-833 - 959-0105. The Administrator of the Chevrolet Protection Plan is Safe-Guard Products International, LLC, Two Concourse Parkway, Suite 500, Atlanta, GA 30328, 1-833-959-0105. 2 Protection Plan coverage runs concurrently with any applicable manufacturer's warranties. 3 In the event of a covered breakdown, rental car expenses up to \$40 per day (max. 10 days) are included in the plan (excludes fuel, collision damage waivers, and optional insurance charges). Authorization required. Exclusions apply. See your dealer for details. 4 Roadside Assistance services may not be available in all states. 5 If required due to a covered mechanical breakdown (max. 5 days). Not available to residents of NY.

© 2026 General Motors. All rights reserved. The marks appearing here are the trademarks or services of GM, its subsidiaries, affiliates or licensors.



For more details

See your Chevrolet Dealer,
Scan the QR code or
Visit chevrolet.com/protection-plans/
chevrolet-protection



PROVIDES EXTENDED COVERAGE BEYOND YOUR WARRANTY FOR UP TO 8 YEARS OR 150,000 MILES, WHICHEVER COMES FIRST.¹

Platinum coverage includes all mechanical parts of your vehicle in the event of a mechanical breakdown, unless they are specifically listed as "not covered" in your Customer Agreement (such as maintenance and cosmetic items).^{2,3}

The Chevrolet Protection Plan covers up to 1,500 parts and components on your vehicle depending on which plan you select.



Engine

- · All internal fasteners, nuts and bolts
- Balance shaft · Boost pressure control
- · Camshaft(s), camshaft bearings,
- buttons and plugs · Common fuel rails
- Crankshaft, pulley, main bearings, caps and bolts
- Cylinder head and gasket
- Emissions-reduction fluid tank, injectors, sensors (including diesel, nitrogen oxide [Nox] and exhaust) and the exhaust particulate filter
- Engine block
- · Engine mounts
- · Engine oil cooler
- · Engine oil cooling hoses and lines
- Flex plate/flywheel and ring gear
- Fuel filter assembly
- Fuel injection control module Fuel temperature sensor

Image Transmission

Adjusters

• Bands

• Oil pan

• Accumulators and rings

· Bearings and bushings

transfer case

Extension housing

· Kickdown cable

· Control rings

• Blockers contained within

· Governor, gear and cover

· Parking gear and pawl

chain and springs

• Planetary and sun gears

· Pressure regulator valve and

· Roll pins, sprags, sprockets,

- Function block
- · Glow plug control system: control/glow plug assembly, glow plugs, cold advance relay and engine control module

· All internal fasteners, nuts and bolts

clutch, drums, pistons and steel plates

Automatic transmission/transayle

• Oil pump, cover, gears, housing and

· Harmonic balance

- Intake and exhaust valves
- · Integral oil cooler
- Oil pan
- Oil pump, cover, gears, pressure relief • Connecting rods and rod bearings valve and screen
 - Pistons, piston rings, pins and cylinder sleeves
 - · Pushrods and lifters
 - · Recirculation and blow-off valve

 - Seals and gaskets
 - · Springs, guides, adjusters, retainers

 - Timing gears and timing chain or belt
 - Transmission adapter plate

 - Valve, timing and side covers
 - Water pump and pulley

☐ ☐ ☐ ◆ Drive Axle

- Intake manifold and exhaust manifolds

- Rotor housing, rotors, shims and silent

- Thermostat
- Thermostat housing
- Turbocharger/supercharger assembly, including boost valve and wastegate

• Speedometer drive gears and sensor

Transfer case and all internal parts

Transmission/transaxle case and all

internally lubricated parts, including ring

Seals and gaskets

· Servos and rings

· Stator and shaft

Supports and shafts

• Torque converter

· Synchronizer hubs and keys

· Transmission cooler hose

• Transmission mounts

· Transmission oil cooler

and pinion gears

• TVI/throttle cable

• Yoke

• Vacuum modulator

Valve body(s), throttle valve

Solenoids

Separate bell housing

. Shift cover and forks

- Axle flange • Center support bearings
- - Gaskets and seals
- · Constant velocity joints and slip joint
- Couplings
 - Flex disc
 - Front-wheel drive axles/halfshafts
- · Limited-slip clutches
 - Pins and retainers
 - Plates and springs Prop shafts
 - Ring and pinion gear/carrier assembly
 - · Spider gears and bearings
 - U-joints
 - · Wheel bearing

切 Hybrid Electrical Components

• Hybrid electric motor clutch Hybrid electric motor

(including control module)

- · Hybrid electric motor clutch actuator Hybrid electric transmission oil pump
- Inverter/converter/transformer units (including all internal components and cover)

• Power split device (including all internal

- Reduction/reducer box (including all internal components)
- Seals and gaskets

Front and Rear Suspension

- · Accumulator, lines and bags
- · Ball joints and bushings
- Coil and leaf springs, seats and bushings Flectronic level control components
- Shafts and bushings
- Shock absorbers · Spindle/steering knuckle and spindle
- · Stabilizer bar, links and bushings

- including pump, accumulator, lines and
- Housing and cartridge

- · Struts and shock absorbers housing and cartridge
- · Tension rods/radius arm and bushings
- Torsion bar
- Torsion bar mount and bushings
- · Track bar
- Upper and lower ball joints Upper and lower control arms.
- · Wheel bearings

- pressure lines and hoses
- Automatic temperature control sensor
- · Clutch assembly, including coil, disc and pullev
- · Compressor, condenser, evaporator seals and gaskets
- Cutoff switch
- Heater blower motor Heater core
- Idler pulley and bearings · Manual climate control unit
- and gaskets Pressure lines and hoses
- Receiver drier Sernentine helt tensioner

Steering

· Air control solenoid

Alarm system or electronic entry

receiver, sender and module

· Alternator mounting bracket

Coolant temperature sensor

Electrical headlamp motors

transmission control module

systems, including remote entry

• Convertible top and sunroof motor

Crank angle and camshaft position

• Cruise control module, servo, cables and

Electronic control modules, including

unit, powertrain control module and

• Electronic throttle control module

Engine and suspension electronic

module and thermo time switch

• Glove box light and courtesy light

bushings and modules

• Front and rear wiper motor,

transmission and linkage

Field coil and rotor

• Fuel pulse dampener

Fuel pump relay

Horn and relay

body control module, electronic control

Electronic ignition and instrument panel

control modules, including body control

Engine distributor, including shaft, gear

Alternator housing, bearings, bushings, brushes, rectifier bridge and diodes

Air regulator valve

Brake light switch

• Cooling fan relay

• Door lock actuators

- · All internal components
- Center link
- Idler arm
- · Joints and couplings • Pitman arms

• IAC motor

- Ignition coil
- · Ignition lock cylinder • Instrument cluster, including
- speedometer, odometer, tachometer and all gauges and warning indicators • Knock sensor and barometric pressure
- Manifold differential pressure sensor
- Manually operated switches MAP sensor
- · Mirror motor switch
- Neutral safety switch
- · Oil pressure sending unit • Oxygen (02) and mass air flow sensors
- · Power seat monitor · Power sliding door motor and switch
- Power trunk/hatch release motor, switch and solenoid
- · Power window and lock switches
- · Power window motor Rear window defogger
- · Ride height sensor and relay • Starter motor housing and all internal
- parts, including brushings, field windings, starter drive and solenoid · Steering column multifunction switch and individual switches for turn signal headlamp, dimmer, wiper, washer and
- speed control • Throttle position and vehicle speed
- sensors
- Throttle position motor Voltage regulators
- · Wide-open throttle switch • Window regulators
- Windshield washer pump

- Steering dampener • Steering linkage
- Internal steering rack seals

- Steering column shafts
- Tie rods ends Tilt wheel mechanism
- · Power-steering pump, tie rods
- Steering column · Intermediate steering shaft
- Seals and gaskets

1 Audio/High Tech

- · Driver vehicle information display
- Blind-spot module · Collision-avoidance module and sensors
- Parking assist module and sensors Forward and rear vision cameras
- · Kevless entry antenna module

Receiver

• GPS antenna

Fuel Systems

• Fuel pulse damper

Fuel pump

• Fuel injectors and seals

- Transmitter alarm module and siren • Radio
- Amplifier

Cellular phone microphone

Antenna

• Speakers and LCD display · Communications control module

Navigation System Components

Navigation computer and display

- Fuel rail and fuel distributor
- Throttle body/control module • TVI/throttle cable

Fuel pump relay

Seals and Gaskets

• Fuel injection control module

- Engine oil pan and gasket
- Head gasket • Rear main seal Timing cover seal
- Valve cover gasket Water outlet gasket

Powertrain

A A







Protection



■★★**■** For more details

See your Chevrolet Dealer, Scan the QR code or Visit chevrolet.com/protection-plans/ chevrolet-protection

***** Climate Control

- Accumulator • Air conditioning/heater blower motor,
- Bearing and pulley Blower motor
- Compressor mounting brackets
- · Control cables

- Orifice tube, expansion valve
- Temperature control head

Gear housing

• Pump seal

Power steering hoses and lines

Rack and pinion

indicator" light is on or your vehicle does not operate properly), and non-factory equipment. Fully electric vehicles, including electric batteries, are excluded from coverage under this Protection Plan.

1 Chevrolet Protection Plan coverage runs concurrently with any applicable manufacturer's warranties. 2 Please consult your Customer Agreement for specific service contract details, including limitations and exclusions. 3 Under Powertrain and Silver coverages, only the specific parts listed in the Agreement are covered. Under Platinum coverage, any of the following parts are excluded: friction clutch disc, pressure plate and clutch release bearings, hinges, glass, glass framework and fastening adhesives, lenses, body parts and/or panels, alignment of body parts, flexible body parts, structural framework, convertible top framework, structural welds, removable hardtop assemblies, bumpers, trim, moldings, weather strips, door panels, door handles, door lock cylinders (other than ignition lock cylinders), tires, wheel covers, wheel balancing, wheel alignment, batteries (Including 12-volt and hybrid batteries), spark plugs, distributor caps, wiper blades, brake pads, linings, rotors and drums, lights, headlamps, sealed beams, fuses, bulbs, LEDs, filters, lubricants or fluids not replaced in conjunction with a covered repair, upholstery, carpet, vinyl and convertible tops, outside ornamentation, paint, chrome and other bright metal, sheet metal, freeze plugs, heater and radiator hoses, exhaust system, catalytic converter, software updates related to multimedia system (unless a "malfunction